

Stainless Steel Strut Cover Installation Instructions

For MGBGT Rear Hatch or MGB Bonnet or Boot

1. Use a broomstick or other means to make sure your rear hatch or bonnet or boot will not accidentally fall while you are working.
2. Remove one strut. A flat blade screwdriver will release the end fittings (snap-on style shown in the first illustration) from the ball-studs they are attached to. (If you have the locking-cap style end-fitting, use a very small screwdriver to carefully remove the cap).
3. Unscrew the end-fitting shown in the second illustration. Sometimes they come off easily by hand. If not, use a crescent wrench and locking pliers or a vise (with brass or wood shims to protect the rod from scratches!) to keep the rod from turning.
4. Slide the Cover on (3rd illustration). If necessary, apply a wrap (more or less) of tape as shown in the third illustration to achieve a snug fit to the cylinder.
5. Replace the end-fitting. Re-install on your MGB.
6. Repeat steps 2 - 5 for the other side.

