

Installation Instructions for MG Crested Carburetor Cap:

1. Remove your existing Cap Assembly from your carburetor and clean the oil off.
2. Make a small gap in your vice and slide your Cap Assembly in the gap. This allows you to use a small punch and hammer to gently tap the Rod Assembly clear of the plastic Cap.



3. Now tighten the Rod Assembly in the vice as shown in the photo. Use a lever and gently pry straight up (not and an angle!) to remove the pressed-on brass fitting from the splined rod as shown in the following photos.



4. Now place your new Cap on a solid flat surface, and simply tap the Rod Assembly into the new Cap until it seats. (Completed assembly shown below is not fully seated--the splines will end up completely (or 95%) inside the brass cap).



5. Be sure to save the gasket from your plastic Cap to reuse on the new Cap.

6. Install and you are done. If you wish to have the logo face a certain direction, we recommend a small drop of Blue Locktite or of silicone caulk on the threads (don't block the vent hole). Position the Cap as you wish and let the Locktite or caulk cure. The Cap will stay oriented, but you will be able to remove it when necessary.